



EMERALD CITY COMPUTER SOLUTIONS, INC.

HOW TO CLEAN A MOUSE

A mouse is a device that is handled a great deal and is therefore subjected to a fair bit of abuse--and dirt. If the ball becomes dirty then it doesn't roll properly, and your cursor won't move smoothly.

Always ensure that the mouse has been unplugged from the back of the PC when cleaning it. Never pour alcohol or other cleaning fluids directly into the mouse.

Make sure that the cable does not get stuck in any part of your desk or workspace, to prevent damage. There should be slack in the cable as well; if it is pulled too tight this can damage the mouse.



Cleaning Instructions

- | |
|--|
| ■ Turn off your computer and unplug from power source |
| ■ Unplug the mouse from the PC |
| ■ Remove the cover from underneath the mouse turning in the direction shown by the arrow |
| ■ Remove the rubber ball from the mouse |
| ■ Pour a small amount of alcohol onto a lint free cloth and gently clean the rubber ball (If you do not have Isopropyl Alcohol then a damp cloth will be sufficient) |
| ■ With the tweezers carefully remove any built up lint or dust that is stuck to the digitisers arms and around the inside of the mouse in general. |
| ■ Wipe over the top of the mouse with a damp lint free cloth |
| ■ Reassemble the mouse and plug in correctly |

New Page 0